

Spectral fitting:

- Calibration uncertainties
- Randomization

Spectral fitting:

- Calibration uncertainties
- Randomization

IACHEC

International Astronomical Consortium for High Energy Calibration

[HOME](#)[NEWS](#)[WORKING GROUPS](#)[MEETINGS](#)[WIKI](#)[PAPERS](#)[RESOURCES](#)[SOURCE DATABASE](#)

14th IACHEC meeting, 20-23 May 2019, Shonan Village Center (Japan)

Welcome to the IACHEC page

The IACHEC aims to provide standards for high energy calibration and supervise cross calibration between different missions. This goal is reached through working groups, where IACHEC members cooperate to define calibration standards and procedures. The scope of these groups is primarily a practical one: a set of data and results (eventually published on refereed journals) will be the outcome of a coordinated and standardized analysis of references sources ("high-energy standard candles"). Past, present and future high-energy mission can use these results as a calibration reference.

Presentation on the IACHEC structure and scope (Lorenzo Natalucci, 1st COSPAR Symposium, 11 November 2013)

Working Groups

- Methodology
 - Calibration Statistics
 - Detectors and Background
 - Contamination
 - Communication
 - Coordinated Observations
 - Heritage
 - High Resolution
 - Timing
- Standard Candles
 - Clusters of Galaxies
 - Non-Thermal SNR
 - Thermal SNR
 - White Dwarfs and Isolated
 - Neutron Stars

News: The 14th IACHEC in Shonan Village in Japan was a success. Talks can be found at **2019**

Mission Links

[Astrosat](#)
[Chandra](#)
[Insight-HXMT](#)
[INTEGRAL](#)
[MAXI](#)
[NICER](#)
[NuSTAR](#)
[Swift](#)
[XMM-Newton](#)

Resource Links


[HEASARC](#)
[SIMBAD](#)
[NED](#)
[ADS](#)
[ArXiv](#)

Search This Site








Search
☐ www ☒ IACHEC

**SNR 1E 0102.2-7219 as an X-ray calibration standard
in the 0.5–1.0 keV bandpass and its application to the CCD
instruments aboard *Chandra*, *Suzaku*, *Swift* and *XMM-Newton***

Paul P. Plucinsky¹, Andrew P. Beardmore², Adam Foster¹, Frank Haber³,
Eric D. Miller⁴, Andrew M. T. Pollock³, and Steve Sembay²




XMM-Newton RGS



General properties of the ARF and RMF

ARF: „Ancillary Response File“, RMF: „Redistribution Matrix File“




EPIC pn: 2067 2067 x 4096 = 8 446 432
vector elements matrix elements

RMF @ EPIC pn: 4096 adu bins from 0.0 to 20.5 ,keV' („EBOUNDS“)
2067 eV bins from 50 eV to 16 keV

EPIC pn RMF: 8.5 million matrix elements
EPIC pn ARFs: 3 x 2067 elements

Residuals obtained with xmmisas RMF



average reduced $\chi^2 = 10.409$

spectral models:

1E 0102

IACHEC model

with **only 1 free parameter:**
global normalization

+ gain fit (offset)

RX J1856


**TBabs *
bbodyrad**

with **all parameters
from
Chandra**
(no free parameter!)

$n_H == 7.25 \cdot 10^{-19} \text{ cm}^{-2}$
 $kT == 62.4 \text{ eV}$
 $\text{norm} == 1.58 \cdot 10^5$

+ gain fit (offset)

Residuals obtained with parameterized RMF



average reduced $\chi^2 = 1.310$

spectral models:

1E 0102

IACHEC model

with **only 1 free parameter:**
global normalization

+ gain fit (offset)

RX J1856

**TBabs *
bbodyrad**

with **all parameters
from
Chandra**
(no free parameter!)

$n_H == 7.25 \cdot 10^{-19} \text{ cm}^{-2}$
 $kT == 62.4 \text{ eV}$
 $\text{norm} == 1.58 \cdot 10^5$

+ gain fit (offset)

Spectral fitting:


- Calibration uncertainties
- Randomization

Calibration uncertainties, especially in the RMF,
are generally not taken into account in spectral fits!


Spectral fitting:

- Calibration uncertainties
- Randomization



Fit to RXJ 1856 (rev 2995, SW, thick)



Fit to RXJ 1856 (rev 2995, SW, thick)



Fits to RXJ 1856 (rev 2995, SW, thick) with the same RMFs and ARFs and the same spectral model, spectra produced in (almost) the same way with the same SAS version (20141104)



difference is probably caused by the randomization within the PHA channels



☑ numerical experiment: process the same data „identically“ 100 times ..

Pairwise comparison of PI spectra from repeated SAS processings (no spectral fit!)

RXJ 1856, SW, thick filter, rev 2995, statistical errors of both spectra considered

worst agreement


best agreement




Pairwise comparison of PI spectra from repeated SAS processings (no spectral fit!)

1E0102, SW, medium filter, rev 3000, statistical errors of both spectra considered


worst agreement



best agreement



*Spectrum accumulated from
1 SAS processing*



Reason for randomization


General problem: how to rebin binned data ?

Occurs frequently:

spectral rebinning: gain & CTI corrections

temporal rebinning: folding pulse profiles

spatial rebinning: projection of pixels, image overlays




Simple example: 400 counts in 10 bins, uniformly distributed

„original“ bin size →

binsize
increased
by factor 1.4 →

distributions
resulting from
binning
unbinned data




Simple example: 400 counts in 10 bins, uniformly distributed

„original“ bin size →

binsize
increased
by factor 1.4 →

distributions
resulting from
binning
binned data,
using the bin
centers


✉ beat pattern,
wrong method



original distribution
(only available in binned form)

new randomization
according to information
in binned data


distributions
resulting from
binning
binned data,
using
randomization



original distribution
(only available in binned form)

new randomization
according to information
in binned data


distributions
resulting from
binning
binned data,
using
randomization



original distribution
(only available in binned form)

new randomization
according to information
in binned data


distributions
resulting from
binning
binned data,
using
randomization



original distribution
(only available in binned form)

new randomization
according to information
in binned data


distributions
resulting from
binning
binned data,
using
randomization



original distribution
(only available in binned form)

new randomization
according to information
in binned data


distributions
resulting from
binning
binned data,
using
randomization









original distribution
(only available in binned form)

new randomization
according to information
in binned data

distributions
resulting from
binning
binned data,
using
randomization



x 100









Refined method: multiply the number of counts per original bin

1

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x 100









Refined method: multiply the number of counts per original bin

2

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x 100









Refined method: multiply the number of counts per original bin

3

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x 100









Refined method: multiply the number of counts per original bin

4

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x 100









Refined method: multiply the number of counts per original bin

5

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x 100









Refined method: multiply the number of counts per original bin

6

with a constant factor (e.g. 100), perform the randomization, and divide the resulting counts by that factor

x 1

x
100



**Running the XMM SAS
100 times
is neither efficient nor elegant**

Is there a better way ?

Probably yes ..

A novel way of processing X-ray data ?

From randomization to probability distributions ..

100 random values per PHA channel
10 sub-bins within each PHA channel



1 000 000 random values per PHA channel
10 sub-bins within each PHA channel




A novel way of processing X-ray data ?

From randomization to probability distributions ..

.. and from PHA channels to PI channels ..

.. for all valid patterns




A novel way of processing X-ray data ?


From randomization to probability distributions ..

.. and from PHA channels to PI channels ..

.. for all valid patterns




A novel way of accumulating an X-ray spectrum



Immediate benefits of propagating probability distributions

less jitter ☑ „better“ fits

☑ reduced uncertainties in spectral parameters




$$s = \sqrt{\frac{1}{N-1} \sum_{i=1}^N (x_i - \bar{x})^2}$$

no randomization necessary ☑ full reproducibility of results



Additional benefit:

possibility of taking spectral gradients into account



- ✓ distortions of the probability distributions can be considered when a spectrum is accumulated
- ✓ this might even improve the spectral resolution

Additional benefit: possibility of taking spectral gradients into account



- ✓ distortions of the probability distributions can be considered when a spectrum is accumulated

✓ this might even improve the spectral

resolution

Randomization appears as an approximation to propagating probability distributions

Drawbacks of the randomization method:

- unnecessarily large jitter in the data
- unnecessarily large χ^2 values
- complications in reproducing the results
- in extreme cases the scientific interpretation may depend on the random number generator



All these drawbacks can be avoided by the method of propagating probability distributions

additional possible benefits:

- ✓ better determination of spectral parameters
- ✓ spectral gradients can be taken into account



Products would be consistent with existing spectral fitting packages and could be made fully backwards compatible

.. perhaps worth a try ?

Spectral fitting:

- Calibration uncertainties
- Randomization

Randomization appears as an approximation to propagating probability distributions and may have a non negligible effect on spectral fits!